
USER GUIDE

2x18" Active/Passive Subwoofers + 2x12" Slim Array Elements Systems





Thank you for choosing KGEAR!

To ensure proper operation, please carefully read this owner's manual and safety instruction before using the product.

After reading this manual, be sure to keep it for future reference.

Should you have any questions about your new device please contact K-array customer service at info@kgear.it or contact the local distributor in your country.

KGEAR by K-array surl via P. Romagnoli 17 - 50038 - Scarperia e San Piero -Firenze - Italy - www.kgear.it

Heavy duty 2x18" subwoofer combined with two metal frame GH12 12" coaxial array modules featuring the K-array™ SAT® technology.

The active GPZA system is powered by a 4-channel Powersoft™ amplifier module with DSP delivering up to 1500 W per channel @ 4 ohm: the built in amp module makes the GPZA capable of driving a GPZ passive system in a stereo configuration.

Unpacking


Each KGEAR device is inspected before leaving the factory. Upon arrival, carefully inspect the shipping carton, then examine and test your new device. If you find any damage, immediately notify the shipping company. Check that the following parts are supplied with the product:

KGEAR GPZA

- 2x GH12 12" array element speaker
- 1x GSX218A active subwoofer
- 1x G-POLE standing pole
- 1x GH-JOINT kit (2 lugs, 8 pins)
- 1x 2m (6.5ft) speaker cable
- 1x 35 cm (14 in) speaker joint cable
- 1x Power cord

KGEAR GPZ

- 2x GH12 12" array element speaker
- 1x GS218 passive subwoofer
- 1x G-POLE standing pole
- 1x GH-JOINT kit (2 lugs, 8 pins)
- 1x 2m (6.5ft) speaker cable
- 1x 35 cm (14 in) speaker joint cable
- 1x 15 m (49 ft) speaker cable




Rear Panel

GPZA - GSX218A

- 1. Status LEDs
- 2. Volume potentiometer
- 3. DSP preset selection button
- 4. RJ45 Ethernet port
- 5. XLR Combo balanced input channel 1
- 6. XLR Combo balanced input channel 2
- 8. NL4 SpeakON A speaker output 1 and 2 amplifier will power up.
- 9. powerCON TRUE AC MAIN inlet

GPZ - GS218

- A. NL4 SpeakON A: signal in/out
- B. NL4 SpeakON B: signal in/out



AC MAINS Supply

GPZA

The GPZA features a powered subwoofer: the AC Main connection is made via the provided power cord with powerCON TRUE flying connector.

Insert the powerCon TRUE flying connector into the inlet and then rotate 7. NL4 SpeakON B speaker output 3 and 4 it clockwise: once properly plugged, the

ArmoníaPlus

ArmoníaPlus is the software for fine tuning and monitoring the KGEAR GPZA loudspeaker system.

Download ArmoníaPlus from Powersoft website: www.powersoft.com



IMPORTANT SAFETY INSTRUCTIONS



CAUTION



ATTENTION: RISQUE DE CHOC ELECTRIQUE NE PAS OUVRIR

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



This symbol alerts the user to the presence of recommendations about the product's use and maintenance.



The lighting flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated, dangerous voltage within the product enclosure that may be of magnitude to constitute a risk of electrical shock.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in this auide.



Operator's manual: operating instructions This symbol identifies the operator's manual that relates to the operating instructions and indicates that the operating instructions should be considered when operating the device or control close to where the symbol is placed.



For indoor use only This electrical equipment is designed primarily for indoor use.



Please dispose of this product at the end of its operational lifetime by bringing it to your local collection point or recycling center for such equipment.



This device complies with Restriction of Hazardous Substances Directive.



Warning. Failure to follow these safety instructions could result in fire, shock or other injury or damage to the device or other property.

General heed and warnings

- Read these instructions.
- Keep these instructions.
- · Heed all warnings.
- · Follow all instructions.
- Do not use this apparatus near water.
- Clean only with dry cloth.
- · Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat
- Do not defeat the safety purpose of the polarized or grounding plug. A polarized plug has two blades with one wider than the other. A grounding plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- Only use attachments/accessories specified by the manufacturer.
- Protect the power cord from being walked on or pinched particularly at the plugs, convenience receptacles, and at the point where they exit from the apparatus.
- Clean the product only with a soft and dry fabric. Never use liquid cleaning products, as this may damage the products cosmetic surfaces.
- · Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/ apparatus combination to avoid injury from tip-over.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Avoid placing the product in a location under direct sunlight or near any appliance that generates UV (Ultra Violet) light, as this may change the product surface finishing and cause a change in color.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

These apparatus are intended for professional use.

Installation and commissioning may only be carried out by qualified and authorized personnel.

- **CAUTION**: These servicing instructions are for use by qualified service personnel only. To reduce the risk of electric shock, do not perform any servicing other than that contained in the operating instructions unless you are qualified to do so.
- **WARNING**: Only use attachments/accessories specified or provided by the manufacturer (such as the exclusive supply adapter, battery, etc.)
- Before turning the power on or off for all devices, set all volume levels to minimum.
- Use only speaker cables for connecting speakers to the speaker terminals. Be sure to observe the amplifier's rated load impedance particularly when connecting speakers in parallel. Connecting an impedance load outside the amplifier's rated range can damage the apparatus.
- KGEAR cannot be held responsible for damage caused by improper use of the loudspeakers.
- KGEAR will not shoulder any responsibilities for products modified without prior authorization.

Service


To obtain service:

- 1. Please have the serial number(s) of the unit(s) available for reference.
- 2. Contact the official KGEAR distributor in your country: or KGEAR headquarter Customer Service.
- 3. You will be contacted back for on-line servicina.
- 4. If the problem cannot be resolved over the phone, you may be required to send the unit in for service. In this instance. you will be provided with an RA (Return Authorization) number which should be included on all shipping documents and correspondence regarding the repair. Shipping charges are the responsibility of the purchaser.


Any attempt to modify or replace components of the device will invalidate your warranty. Service must be performed by an authorized K-array service center.

Assembling instructions

Tightly screw the G-POLE on top of the subwoofer, then set the GH12 12" array element on top of the G-POLE.




Install the GH-JOINT kit on top of the at info@kgear.it. Please describe the GH12 loudspeaker: insert the four pins on problem clearly and completely to the the holes according to the desired tilting angle.



GPZA / GPZ



Secure the second GH12 on top of the system using the remaining four pins.



Set the height of the pole and the tilting angle of the top loudspeaker aiming at the listening area.


GPZA wiring

Once assembled, use the 2m (6.5ft) long speaker cable to connect one speakON connector on the GH12 rear panel to the speakON A connector on the active subwoofer rear panel.

Use the short joint cable to connect the top GH12 to the bottom GH12 loudspeaker.

By default, the input signal shall be fed with a pair of cables connected to the XLR Combo balanced input channels 1 and 2 on the GP18A active loudspeaker rear panel.


If only one cable is used to feed the input channels 1 or 2, the mono configuration can be set with ArmoníaPlus.



GPZ wiring

The GPZ must be bi-amplified feeding the speakON B (on the subwoofer rear panel) with two signals: one for driving the GH12 array loudspeakers on terminals 1+ 1-, the other one for driving the GS218 subwoofer on the speakON B terminals 2+ 2-.

The GP1812A active system implements a 4-channel amp module with DSP: a single GP1812A can drive a GP1812 passive systems in stereo mode.





SpeakON B to SpeakON B


Once assembled, use the the 2m (6.5ft) long speaker cable to connect one speakON connector on the GH12 rear panel to the speakON A connector on the active subwoofer rear panel.

Use the the 15 m (49 ft) long speaker cable Cleaning to connect one SpeakON B connector on (i.e. a GPZA active system).

SpeakON A and speakON B connected in parallel in order to make the signal pass through (see next picture).







Use only a soft, dry cloth to clean the subwoofer rear panel to the driving unit the housing. Do not use any solvents, chemicals, or cleaning solutions containing are alcohol, ammonia, or abrasives. Do not use any sprays near the product or allow liquids to spill into any openings.

Remote Control With Armonía Plus

The built-in DSP can be remote controlled and tuned with the ArmoníaPlus software over an Ethernet network.

ArmoníaPlus 1. Download from Powersoft website and install it on your PC.




- Launch Armonía Plus.
- 3. Log-in with your ArmoníaPlus account.
- 4. The first time you launch Armonía Plus vou need to download the KGEAR amplifiers presets form the Armonía Plus marketplace.




5. Insert «KGEAR» in the search field and add the support to the KGEAR devices you need.




6. Connect the PC with ArmoníaPlus and your KGEAR device to the same local network.




7. Click on the Match button in the bottom toolbar.



8. Check that the wired network interface is active an that the Synchronization mode is ON.



- 9. Click on the Discovery button.
- 10. Wait until Armonía Plus shows the device, then drag-and-drop the device from the right panel to the Workspace (left panel): the system takes few seconds to synchronize.
- 11. In order to access the device properties, select the pointer in the bottom toolbar and then double-click on the device in the Workspace.



12. You can eventually work off-line in Setting Device Preset «Design» mode: click on the Add button in the bottom toolbar.



13. In the top menu bar, click on the button labeled «Powered Speaker».



14.In the new window select the Brand / Family / Model / Application according to your needs, the click on Add.



15. The device(s) will be added to the Workspace.

The rear panel features four preset buttons that can be assigned to custom device preset.


A device preset includes the entire configuration of the four output channels and input equalization.

In order to customize the current device preset:

- A. connect the device to Armonía Plus:
- B. make your settings;




C. go to the preset windows and click on the Save button: the current device configuration will override the previous settinas.




GPZA / GPZ


KGEAR Smart Audio Solutions


Mechanical Drawings














Technical Specifications

GPZA

To about all ama aifi antiama
Technical specifications
ype Powered Sub + Satellite system
ransducers SUB: 18" woofer "OP: 12" coaxial woofer and 1" compression driver
requency Response 50 Hz - 20 kHz (-6 dB)
lax SPL ¹ 29 dB (peak)
overage 7. 30° H. 90°
mp Module I-channel Class-D
utput Power Ix 1500 W @ 4 Ω
perating Voltage 00-240V AC, 50-60 Hz
ower Consumption 500W Rated Load, (1/8 Max Output Power)
OSP Features Remote control and tuning Remote and Output Delay Parametric input EQ Dutput parametric filters
onnectors RJ45 for remote control Ex Combo XLR Input Ex SpeakON Output x PowerCon True AC MAINS
ontrols /olume potentiometer Preset selector Remote control through Powersoft ArmoniaPlus Software
imensions (WxLxH) 035 x 2040(min) x 600 mm (40,75 x 80,31 x 23,6 ir
Veight 90kg (198.4 lb)

1 Maximum SPL is calculated using a signal with crest factor 4

(12dB) measured at 1 m.

Technical specifications Type

GPZ

Passive Sub + Satellite system

Transducers
SUB: 18" woofer
TOP: 12" coaxial woofer and 1" compression driver

Frequency Response
30 Hz - 20 kHz (-6 dB)

Max SPL¹
129 dB (peak)

Coverage
V. 30° | H. 90°

Power Handling
SUB: 1500W | TOP: 400W

Nominal Impedance
SUB: 4 Ω | TOP: 32 Ω each satellite

Connectors
2x NL4 SpeakON (TOP: 1+, 1- SUB 2+, 2-)

Dimensions (WxLxH)
1035 x 2040 (min) x 600 mm (40,75 x 80,31 x 23,6 in)

 Maximum SPL is calculated using a signal with crest factor 4 (12dB) measured at 1 m.

Weight 86,6 (190.9 lb)